

Painting the stencil



To prevent overspray, it is a good idea to tape some newspaper over the top and bottom of the stencil to protect the surrounding area.



Brush the concrete free of any dirt. Brush away from the drain to prevent sweeping material in.



Put the stencil in place. It is best to have two people wearing gloves helping to hold down the stencil

It is VERY important to use quick light strokes back and forth with the spray paint! Trying to get a thick coverage will result in paint running under the stencil.



Make sure the stencil is flat against the ground. If it is raised, paint will escape under the edges ruining the stencil. You may need to hold down edges near the part you are spraying if the surface is uneven.

[Tip: keep your hand moving whenever the nozzle is pressed. If your hand stays still while pressing the nozzle, too much paint will go to one spot and it will run]